

# Test Ticket Print Out

## Printing a Self-test Ticket on the EPIC 950

The Epic 950 printer has the ability to print a pre-defined self-test ticket, to test the normal printing functionality of the unit, and create a printout of the current printer configuration. To print a self-test ticket, perform the following steps:

1. Unrack the Inner Chassis.
2. Open the Ticket Cover. Do not remove a currently loaded ticket.
3. Press and hold the feed button until the Open LED goes out, then release this button.
4. Now close the Ticket Cover, and the self-test ticket will then print.
5. Close the Inner Chassis to resume normal operation.

At right is an example of the information printed. Your printer may print more or less information, depending on the version and revision of the printer.

